



# Zyxel 3925 Wireless Setup

**NOTE:** By default your wireless is on, the wireless name and Password are on a sticker on the bottom of the Zyxel router. If you would like to change the name of your wireless or password follow the instructions below or you can call tech support for help.

## STEP 1:

- Open Browser (Fire Fox,Safari, Internet Explorer, etc.)
- Empty Address Bar
- Enter: **192.168.1.1**
- Press **ENTER**



**NOTE:** Instruction

## STEP 2:


Username: **user**  
Password: **veiwoonly1**



## STEP 3:

On the bottom toolbar, Choose **Network Settings**

Choose **Wireless**



## STEP 4:

Change Wireless Name  
**Wireless Network Name**  
(Also has 5g. You can make it the same with a check mark, or change it by using the drop down.)

### Wireless Network Settings

Wireless Network Name(SSID):

ZyXEL57253

Hide SSID

Client Isolation

MBSSID/LAN Isolation


Enhanced Multicast Forwarding

BSSID:

EC:43:F6:40:3A:44

## STEP 5:

- Un-check **Generate Password**
- Choose **Security Mode**
- Enter your New Password
- Click **Apply**



**Congratulations—you're done!**