



Zyxel 660 WiFi Setup

NOTE: By default your wireless is on. The wireless name and password are on the sticker located on the bottom of the Zyxel router. If you would like to change the name of your wireless network or password, follow the instructions below. Please call MTE Tech Support if you require additional assistance.

STEP 1:

- Open Browser (Fire Fox,Safari, Internet Explorer, etc.)
- Empty Address Bar
- Enter: **192.168.1.1**
- Press **ENTER**




STEP 2:

- User Name: **user**
- Password: **veiwonly1**
- Click **Login**



STEP 3:

Choose **Network Settings**
Choose **Wireless**



STEP 4:

Change Wireless name:
Wireless Network Name

Wireless Network Settings

Wireless Network Name(SSID):

ZyXEL57253

Hide SSID

Client Isolation

MBSSID/LAN Isolation


Enhanced Multicast Forwarding

BSSID:

EC:43:F6:40:3A:44

STEP 5:

- Uncheck **Generate Password**
- Choose **Security Mode**
- Enter **New Password**
- Click **Apply**



Congratulations—you're done!